

MANUAL INJECTION PUMP

Technical datasheet Nr 23

This pump is designed for topping up the LACAZE ENERGIES heat transfer fluid in your solar installation.


• DESCRIPTION:

- Manual injection pump with non-return valve designed to increase the pressure in the system and to refill the latter with heat transfer fluid.
- 1/2" external thread self-sealing with O-ring, 15 mm tube connection.
- Pump output 2 l/min, pressure 4,5 bar max.



Reference : 90080100046

• CONNECTING THE MANUAL INJECTION PUMP:



For ease to use, install the top-up pump perpendicular to the wall.